making interiors spectacular






Table of Contents

- 5 Case / Base Combinations
- 7 Architraves
- 8 Casings
- 9 Casings & Baseboards
- 18 Baseboards, Shoes & Caps
- 18 Brickmoulds & Lattice
- 19 Wall Trim (Wainscot & Chair Rail)
- 20 Chair Rails
- 20 Corners & Squares
- 21 Mantel Trim Options
- 22 Door & Window Trim Options (Headers)
- 23 Panel Moulds
- 23 Coves
- 23 Quarter, Half & Full Rounds
- 24 Stops & Battens
- 24 Handrails
- 25 Ceiling Trim Options (Crowns)
- 27 Crowns
- 30 Miscellaneous Profiles
- 32 Finish Lumber (S4S)
- 33 Door Jambs
- 33 Embossed Pre-Finish
- 34 Jambs
- 35 Product Index
- 37 Moulding Gallery
- 38 Corporate Map





- ARCHITRAVES: In classical architecture, it described the main beam resting on the tops of the columns. Today it is often used as a decorative moulding for ornamentation or finishing at the top of windows and doors.
- **BASEBOARDS:** Baseboards are placed along the wall at the floor. They should be chosen to work in harmony with your casings to finish and tie the room together. Baseboards are usually thinner than the casing.
- BUILD-UPS: Combining two or more moulding profiles to create a new or custom look. Also called stacking, build-ups make it easy to create the look of custom made trimwork without the high cost.
- 4 CASING: Casings define the overall character of a room and are often the most visible part of the trim. They are used primarily to cover the gap between drywall and the door or window frame. Casings are generally thicker than the base mouldings.
- 5 CROWNS: Crowns are placed along the wall at the ceiling. They come in a wide range of patterns and sizes. Crowns soften the transition from wall to ceiling while adding a distinctive look and charm to your room.
- 6 FINISH BOARDS: Finish Boards come in either S4S (Surfaced 4 Sides) or S3S (Surfaced 3 Sides) and are used for a multitude of purposes including shelving, window liner, bases, casing, etc.
- 7 LATTICE: A Lattice is a thin strip of flat moulding commonly used to hide seams and trim edges. It is available in a multitude of widths and is useful for a wide variety of projects.
- 8 PANEL MOULDS: Panel Moulds are used to frame wall paneling and add an accent to your walls. Often used in furniture construction.
- (9) RAKE MOULD: Rakes are often used as crowns. In fact, they are sometimes called "solid crowns".
- WAINSCOT: Trimwork installed in the area below a chair rail. Numerous options are available including raised panel, shadow box and beaded. Combined with a chair rail and baseboard, Wainscoting creates a dramatic look to any room.
- window stool: Also called window sill, a Window Stool is the surface installed below the sash of a window. Trim installed under window stool creates a distinctive look and adds a decorative touch.



Glossary of Terms

BASE SHOES: Base shoes are primarily used to trim flooring materials and are often used in combination with a traditional baseboard to conceal variations between the flooring and the base. However, this versatile profile works great to solve numerous trimming needs.

BATTENS: A Batten is a narrow strip of wood used to cover joints or as decorative vertical members over plywood or wide boards.

BEADED CEILING: A popular profile used often as wainscot paneling. Combined with a chair rail or cap mould and a baseboard, beaded ceiling makes a distinctive wainscot package. **BRICKMOULDS:** A Brickmould is mainly used as exterior casing around doors. 2 inches is the most common size, however, 1-1/2 and 1-1/4 inch sizes are available. Brickmoulds can also be used in place of a crown, and as a transition under window sills.

BULLNOSE: A term used to describe the eased edges of trim and stops. A single bullnose stop would have one eased edge and a square edge back. A double bullnose stop would have two eased edges.

CHAIR RAILS: Chair Rails are practical as well as decorative. Applied to a wall, from 24 to 48 inches up from the floor, they protect the wall from scuffs and dents from the backs of chairs as well as adding a beautiful accent to any room.

CORNERS: Corners are used to protect the outside edges of the wall from damage and abrasion. Corners come in a wide variety of sizes and detailing.

COVES: Coves are commonly used to soften the transition on inside corners but may be used for a wide range of applications.

DENTIL: A moulding pattern with a series of closely spaced rectangular blocks and spaces. Used especially in classic architecture.

DOOR STOPS: The Door Stop mouldings are attached to the door jamb on both sides and at the top. It is where the door comes to a rest when it is closed stopping the door from moving any further, and covering the gap that would otherwise appear between the door and the jambs.

FULL ROUNDS: Full Rounds are used for numerous purposes and projects. Some of the more common uses are closet poles, curtain rods and towel rods.

HALF ROUNDS: A cross section of a Half Round looks like a half circle and is used primarily as decorative trim. It works well as a trim piece for wall paper or to add a decorative pattern to flat panels. This profile can also be used to put a rounded edge on various shelving.

HANDRAILS: Handrails provide safety and support.


QUARTER ROUNDS: Quarter Rounds come in several sizes and serve a variety of functions. They are most often used with baseboards.


RETURN: Term used to indicate the method of carrying a mouldings detail from the front of the moulding back to the wall. Generally a 45 degree cut is made to the front of the long moulding and an opposite 45 is cut on a small piece to carry the detail to the wall.


SCREEN MOULD: A very versatile profile; Screen Mould fits a wide variety of needs and uses. Traditionally used to hold mesh screening into wood screens, it also works well as edge trim on various shelving or wood trim for wall paper etc.


SQUARES AND PARTING BEADS: Squares and Parting Beads are used in a wide range of applications including filling gaps and transitioning heights. This profile may also be used in a variety of craft projects.


Case/Base Combinations







































Case/Base Combinations option 2 option 3 option 1 Casing #001 < Casing #411 < Casing #410 < #412 #412 option 4 option 5 option 6 Casing #535 Casing #1001 Casing #100 Baseboard #545 \ Baseboard Baseboard #200 option 7 option 8 Casing #3005 Casing #1208 Casing #1208 Baseboard #653 Baseboard Baseboard #673 option 10 option 11 option 12 Casing #003 Casing #019 Casing #033 Baseboard Baseboard #623 \ #003 option 13 option 14 Casing #472 Casing #472 < Baseboard Baseboard #495






ALL SIZES NOMINAL




340		BDL
9/16" x 3-1/8	LDF Primed	1



908		BDL
9/16" x 3-1/4"	Ultralite	7




312	25	BDL
1/2" x 3-1/4"	FJ Primed	10



1001		BDL
5/8" x 3-1/4"	Hemlock	6



386		BDL
5/8" x 3-3/8"	LDF Primed	1





907		BDL
9/16" x 2-1/4"	Ultralite	10



540		BDL	
11/16" x 5-1/4"	LDF Primed	1	







535		BDL
11/16" x 3-1/2"	Hemlock	6
3/4" x 3-1/2"	Ultralite	6



545		BDL
9/16" x 5"	Hemlock	3
9/16" x 5"	Ultralite	3



8063		BDL
11/16" x 3-1/4"	Ultralite	8



8263		BDL
9/16" x 6-1/2"	Ultralite	3

3122		BDL
1" x 3-1/2"	Ultralite	8

3121		BDL	
9/16" x 2-5/8"	Ultralite	10	




ALL SIZES NOMINAL



410	0	BDL
11/16" x 2-1/4"	Hemlock	8
11/16" x 2-1/4"	Ultralite	8



411		BDL
5/8" x 3"	VG Fir	10
11/16" x 3"	Hemlock	6
11/16" x 3"	Ultralite	6



412		BDL
9/16" x 4-1/4"	VG Fir	10
9/16" x 4-1/4"	Hemlock	6
9/16" x 4-1/4"	Ultralite	6



215		BDL
5/8" x 3-7/16"	Hemlock	10



321		BDL
5/8" x 2-1/4"	Hemlock	12



414

9/16" x 5-1/4" Ultralite

415		BDL	
9/16" x 2-3/16"	LDF Primed	6	

BDL

Casings & Baseboards

ALL SIZES NOMINAL



001		BDL
7/16" x 2-3/16"	Hemlock	10

010		BDL
7/16" x 1-1/2"	Hemlock	20

493 BDL 1/2" x 2-1/4" Hemlock 10




473		BDL
5/8" x 2-1/4"	VG Fir	8
9/16" x 2-1/4"	LDF Primed	6



V		
7/16" x 2-1/4"	Hemlock	10
3014		
301	4	BDL

BDL

310	3102	
7/16" x 3-1/4"	Hemlock	10



472		BDL
9/16" x 2-1/2"	Ultralite	10
5/8" x 2-1/2"	Hemlock	1
5/8" x 2-1/2"	VG Fir	1

49	4	BDL
1/2" x 3-1/4"	Ultralite	10
49)5	BDI

495	5	BDL
5/8" x 3-1/2"	Hemlock	1
5/8" x 3-1/2"	VG Fir	1
11/16" x 3-1/2"	LDF Primed	1



669		BDL
7/16" x 5-1/2"	Hemlock	1






ALL SIZES NOMINAL




300)5	BDL
1/2" x 1-1/2"	Hemlock	20
1/2" x 1-1/2"	FJ Primed	30

5/8" x 5"

LDF Primed



653		BDL
3/8" x 3-1/4"	Hemlock	10
3/8" x 3-1/4"	FJ Primed	10



66	3	BDL
1/2" x 4-3/16"	FJ Primed	8
3/8" x 4-1/4"	Hemlock	10



BDL		094	BDL
6	5/8" x 4"	LDF Primed	6




L	0	93	BDL
	5/8" x 3-1/4"	LDF Primed	6

673	1	BDL
3/8" x 5-1/4"	Hemlock	6
9/16" x 5-1/8""	FJ Primed	8



//" I DE Primed 6 5/9" x 2 1/2" I DE Primed 6	BDL 092 B	BDL	BDL	92	09	BDL)3	09
74 LDI I'IIIIled 0 3/6 X 2-1/2 LDI I'IIIIled 0	ed 6 5/8" x 2-1/2" LDF Primed	6	6	LDF Primed	5/8" x 2-1/2"	6	LDF Primed	/4"



31	0	BDL
1/2" x 4-1/8"	LDF Primed	4

620		BDL
1/2" x 5-1/4"	LDF Primed	4

207	'	BDL
5/8" x 7-3/16"	Ultralite	6

Casings & Baseboards


ALL SIZES NOMINAL




754		BDL
11/16" x 3-1/4"	Hemlock	5
11/16" x 3-1/4"	LDF Primed	1



750		BDL
5/8" x 5-1/4"	LDF Primed	6
5/8" x 5-1/4"	Hemlock	4



751		BDL
5/8" x 7-1/4"	Hemlock	1



Casings & Baseboards

ALL SIZES NOMINAL



100		BDL	
5/8" x 2-3/16"	Hemlock	10	
11/16" x 2-3/16"	Ultralite	8	



200		BDL
7/16" x 3-1/4"	Hemlock	10
1/2" x 3-1/4"	Ultralite	8




125		BDL
9/16" x 2-1/16"	Hemlock	10



356		BDL
1/2" x 2-1/8"	Oak Veneer	10
7/16" x 2-1/8"	Oak	10
5/8" x 2-1/4"	VG Fir	10
5/8" x 2-1/4"	Hemlock	10
9/16" x 2-1/4"	Ultralite	12
5/8" x 2-1/4"	FJ Primed	12
9/16" x 2-1/4"	LDF Primed	6







444		BDL
7/16" x 3-3/16"	FJ Primed	10
9/16" x 3-1/8"	Hemlock	10
9/16" x 3-1/8"	Ultralite	6
5/8" x 3-1/8"	LDF Primed	6



3000		BDL
1/2" x 1-1/2"	Hemlock	20
7/16" x 1-7/16"	Oak	10
1/2" x 1-5/8"	LDF Primed	6

_		
300	2	BDL
1/2" x 2-3/16"	Hemlock	10
7/16" x 2-1/4"	Oak	10
7/16" x 2-1/4"	Oak Veneer	10
9/16" x 2-5/16"	LDF Primed	6



258

11/16" x 2-3/16" Hemlock

9/16" x 7-1/4" Ultralite

8312

1/2" x 4-1/4" LDF Primed




ALL SIZES NOMINAL




165 Base Cap		BDL
3/4" x 1-1/8" Hemlock		20

S4S





326		BDL
9/16" x 3-3/8"	LDF Primed	4



635		BDL
9/16" x 5-5/8"	LDF Primed	4

Brickmoulds & Lattice


ALL SIZES NOMINAL




995		BDL
3/4" x 3/4"	Hemlock	1000′



507		BDL
1-3/16" x 1-1/2"	Hemlock	8



180		BDL
1-3/16" x 1-15/16"	Hemlock	4
1-3/16" x 1-15/16"	FJ Primed	8




1/4" x 1-3/8" Hemlock 30	2//	7	DD.
	1/4" x 1-3/8"	Hemlock	30

266		BDL
1/4" x 1-5/8"	Hemlock	30

264		RDL
1/4" x 2-1/4"	Hemlock	20

Wall Trim Options (Wainscot & Chair Rail)



Base Cap

Paintable/Stainable

#165

Paintable/Stainable

Baseboard

Paintable/Stainable

#623

Paintable

Chair Rails

ALL SIZES NOMINAL



706 Pa	nel Cap	BDL
3/4" x 2"	VG Fir	10
3/4" x 2"	Hemlock	10



292		BDL
9/16" x 1-1/8"	Hemlock	20





184		BDL
5/8" x 2-1/4"	Hemlock	6

BDL

10

297		BDL
5/8" x 3"	Hemlock	6
5/8" x 3"	LDF Primed	4
11/16" x 3"	Ultralite	6

Corners & Squares

ALL SIZES NOMINAL



3428		BDL
1/2" X 3/4"	Hemlock	25
1/2" X 3/4"	FJ Primed	25




5/8" x 1-3/8"


702 Panel Cap

Hemlock


3517		BDL
1-1/16" x 1-1/16"	Hemlock	9

3516		BDL
11/16" x 11/16"	FJ Primed	25
3/4" x 3/4"	Hemlock	25








Mantel Trim Options



Door & Window Trim Options (Headers)





































1/2" x 1"

1/2" x 1"



704		BDL
5/8" x 5/8"	Hemlock	10





Hemlock

FJ Primed


20

20

703 BDL 7/16" x 3/4" Hemlock

11/16" x 11/16" FJ Primed

30



Quarter, Half & Full Rounds

ALL SIZES NOMINAL



	3212	
3/8" x 3/4	" Hemlock	25



3202		BDL
1/2" x 1/2"	Hemlock	25
1/2" x 1/2"	Oak	20

3200		BDL
1/4" x 1/4"	Hemlock	25

3206		BDL
11/16" x 11/16"	Hemlock	25
11/16" x 11/16"	Oak	20
11/16" x 11/16"	FJ Primed	30



3222		BDL
11/16"	Hemlock	25
3	3224	BDL
1-1/16"	Hemlock	10
3226		BDL
1-5/16"	Hemlock	10
3228		1
	3228	BDL

Stops & Battens

ALL SIZES NOMINAL



3422		BDL
5/16" x 1-3/16"	Hemlock	30
3/8" x 1-1/4"	FJ Primed	30



936		BDL
3/8" x 1-3/8"	Hemlock	20
3/8" x 1-3/16"	FJ Primed	20



327	BDL	
1/4" x 3/4"	FJ Primed	50
1/4" x 3/4"	Hemlock	50
1/4" x 3/4"	Oak	30



865		BDL
7/16" x 1-1/2"	Hemlock	20

866		BDL
7/16" x 1-5/16"	Hemlock	20

869		BDL
7/16" x 1-1/16"	Hemlock	20




593		
1/2" x 1-11/16"	LDF Primed	6

Handrails

ALL SIZES NOMINAL





3507		BDL
1-3/16" x 2-1/4"	Hemlock	4





231		BDL
1-7/16" x 1-5/8" Hemlock		6
1-7/16" x 1-5/8"	FJ Primed	6


Ceiling Trim Options (Crowns)






















































Ceiling Trim Options (Crowns)


#3244








3244		BDL
9/16" x 1-1/4" Hemlock		20
5/8" x 1-3/16"	FJ Primed	24

3248		BDL
1-3/16" x 2-1/4"	Hemlock	4
1-3/16" x 2-3/16"	FJ Primed	8













1-7/16" x 3-1/8" FJ Primed





284 Backband		BDL	
1-1/8" x 1-9/16"	Hemlock	8	





216		BDL
5/16" x 3-1/4"	Hemlock	10

Beaded C	BDL	
9/16" x 3-1/4"	Hemlock	6
9/16" x 3-1/4"	VG Fir	6

496 Back	splash	BDL
7/16" x 3-1/2"	Maple	6
7/16" x 3-1/4"	Oak	6



22	222					
9mm x 5-3/4"	LDF Primed	1				



9531 Opening Trim								
7/16" x 1-1/4"	Hemlock	10						
7/16" x 1-1/4"	LDF Primed	6						



004 Back	BDL	
1-1/8" x 1-5/16"	Hemlock	8



953	BDL	
7/16" x 1-1/4"	Hemlock	10-20
7/16" x 1-1/4"	LDF Primed	6
7/16" x 1-1/4"	VG Fir	10-20

Finish Lumber (S4S)

ALL SIZES NOMINAL

VG Hemlock

VG Douglas Fir

Red Oak


Maple

Pine Boards

Primed Fingerjoint

LDF Primed

Ultralite Supercoat LDF



	1x2	1x3	1x4	1x4-1/2	1x5	1x6	1x7	1x8	1x10	1x12	2x2	2x3	2x4	2x6	2x8	4×4	1/2x3	1/2×4	1/2x5	1/2x6	5/4x4	5/4x6	5/4x8
VG FIR	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
VG HEMLOCK	Х	Х	Х		Х	Х	Х	Х	Х	Х	Х						Х	Х	Х	Х	Х	Х	Х
KNOTTY PINE			Х			Х		Х	Х	Х													
OAK	Х	Х	Х		Х	Х		Х	Х	Х	Х		Х	Х	Х			Х		Х			
FJ PRIMED	Х	Х	Х		Х	Х	Х	Х															
LDF PRIMED	Х	Х	Х		Х	Х	Х	Х	Х	Х								Х		Х	Х	Х	Х
ULTRALITE	Х	Х	Х		Х	Х	Х	Х	Х	Х													
MAPLE	Х		Х		Х		Х																

Pacific Coast Hemlock

Your natural choice.
Accepts paints, stains & natural finishes very well. Combined with Hemlock mouldings for a great decorating choice.

VG Douglas Fir

For the northwest feel. Fine grain Douglas Fir makes a beautiful project when finished with a clear finish coat.

Primed Fingerjoint

Short pieces of wood joined together to make long pieces that are primed and ready to top coat. Ideal choice for those that like to work with solid wood.

Ultralite Supercoat

One-third less weight than regular MDF, a super smooth primer and easy to nail; Ultralite is the ideal choice for most paint grade projects.

LDF Primed

MDF offers standard builder lengths, 100% defect free with no knots, no checks, no splits, no raised or torn grains, more resistant to dings and dents.

Door Jambs

ALL SIZES NOMINAL


	IN-STOCK DOOR JAMBS												
HEMLOCK		SOLID FIR		PRIMED FJ	LDF PRIMED								
INTERIOR	EXTERIOR	INTERIOR	EXTERIOR	INTERIOR	EXTERIOR	INTERIOR							
4-9/16 FLAT	4-9/16 KERFED	4-9/16 COMBO	6-9/16 KERFED	4-9/16 FLAT	4-9/16 KERFED	4-9/16 DBL RAB							
4-13/16 FLAT	4-9/16 KERFED 8'		7-1/4 KERFED 8'	4-9/16 DBL RAB	4-13/16 KERFED	4-13/16 COMBO							
4-13/16 S/APPLIED	5-1/4 KERFED			4-9/16 COMBO	5-1/4 KERFED								
4-9/16 S/APPLIED	6-9/16 KERFED			4-9/16 COMBO 8	6-9/16 KERFED								
4-9/16 DBL RAB	6-9/16 KERFED 8			4-13/16 FLAT	6-9/16 KERFED 8								
4-9/16 DBL RAB 8	7-1/4 KERFED			4-13/16 COMBO	6-13/16 KERFED								
4-9/16 COMBO				5-1/4 COMBO	7-1/4 KERFED								
4-13/16 COMBO				6-9/16 FLAT	7-1/4 KERFED 8'								
5-1/4 COMBO				6-9/16 COMBO	8-7/8 KERFED 8'								
6-9/16 COMBO				6-9/16 COMBO 8									
6-9/16 COMBO 8'				7-1/4 COMBO									
7-1/4 COMBO													

Embossed Pre-Finish

ALL SIZES NOMINAL

Mouldings, Jambs and Boards (all items on wood substrate unless noted)


		Golden Oak	Strand Oak	Alpine Oak	Natural Oak	Maple	Fawn	Newport Cherry	Spiced Ash
356 Colonial Casing	7/16 x 2-1/4	Х	Х	Х	Х	Х	Х	Х	Х
3000 Bevel Casing	7/16 x 1-7/16	Х	Х	Х	Х	Х			
3002 Bevel Casing	7/16 x 2-1/4	Х	Х	Х	Х	Х			
473 Casing	7/16 x 2-1/4							Х	Х
624 Baseboard	3/8 x 2-3/4							Х	Х
573 Baseboard	3/8 x 3-1/4							Х	Х
493 Stop	3/8 x 1-11/16	Х	Х	Х	Х	Х	Х		
3422 Stop	3/8 x 1-1/4	Х	Х	Х	Х	Х			
1x2	11/16 x 1-1/2	Х	х	Х	Х	Х	Х	X-LDF	X-LDF
1x4	11/16 x 3-1/2	Х	Х	Х	Х	Х	Х	X-LDF	X-LDF
1x5	11/16 x 4-9/16	Х	Х	Х	Х	Х	Х	X-LDF	X-LDF
1x6	11/16 x 5-1/2	Х	Х	Х	Х	Х	Х	X-LDF	X-LDF
1x7	11/16 x 6-9/16	Х	Х	Х	Х	Х	Х	X-LDF	X-LDF
1x8	11/16 x 7-1/4	Х	Х	Х	Х	Х	Х	X-LDF	X-LDF
1x10	11/16 x 9-1/4	Х	Х	Х	Х	Х	Х	X-LDF	X-LDF
1x1	11/16 x 11-16	Х	х	Х	Х	Х	Х	Х	Х
4-9/16 Flat Jambs	11/16 x 4-9/16	Х	х	Х	Х	Х			
4-9/16 Stop Applied Jambs	11/16 x 4-9/16	Х	Х	Х	Х	Х	Х	Х	Х
4-13/16 Stop Applied Jambs	4-9/16 x 81-5/8	Х	Х	Х	Х	Х	Х	Х	Х
4-13/16 Single Rabbet Kerf (20 min)	4-13/16 x 83	Х	Х	Х	Х	Х	Х	Х	Х
6-13/16 Singe Rabbet Kerf (20 min)	6-13/16 x 83	Х	Х	Х	Х	Х	Х	Х	Х



Storage, Handling and Preparation of all Mouldings and S4S Boards

Until the time this product has been correctly **final coated (after painting or staining)** and installed, in conformance with all paint manufacturer recommendations as well as the highest and best building practices, respectively, for intended use, it must be **continuously and effectively protected from exposure to direct sunlight, ground contact and the elements.** It should be **stored only in a dry, clean location** and **transported only if fully protected from water.** As a final preparation before installation: **(a) indoors,** the product **must be** "acclimated" to the environment by storing it in the installation space for at least 3 days (with both faces exposed to the air in that space); **(b) outdoors, every surface lacking both primer and final coat must be effectively coated** to achieve protection recommended by the paint manufacturer respecting intended use.


Product Index



Product Index

9/16" x 3-1/4"

pg31



1-7/16" x 3-1/8"

pg 30

9/16" x 3-5/16"

pg31







